



BLUETOOTH 4.0 FTMS
Connects to 3rd Party Apps

CR800 SEMI-RECUMBENT BIKE



OPTIONAL EQUIPMENT
TV Bracket (TV not included)

The CR800 Semi-Recumbent Bike is the perfect bike for the commercial environment. The step-through design and easy-adjust seat makes it easy for your clients to get on the bike and quickly find the most comfortable seat position. The intuitive console offers multiple program options and up to 40 levels of resistance to keep your clients interested and motivated. The extra smooth ride comes from the perfected gearing and the integrated generator/flywheel system.

CR800 SEMI-RECUMBENT BIKE

- Built-in contact and telemetric heart rate capabilities for a more effective workout
- Generator-powered console means there is no need for outlets or power cords
- Oversized foot pedals with fast-latching system
- Contoured high-density foam seat for extra comfort during a long ride
- 40 levels of resistance to satisfy the needs of beginners or advanced exercisers
- Adjustable cooling fan and dual storage trays



18-character message center

Track and program profile window

Tablet-friendly reading rack

Adjustable fan angle

Ten effective programs

Fan on/off

USB charging port

Easy-touch control buttons

CR800 CONSOLE FEATURES

The electronics in the CR800 are designed to provide intuitive operation. The console features a large easy-to-read display with a variety of program options for users of all fitness levels, an integrated fan to keep clients cool, and a USB port to help keep their devices charged. The convenient seat-mounted hand pulse grip sensors provide heart rate monitoring on demand.

EQUIPMENT SPECIFICATIONS

Console	white multi-window LED displays (18-character message center, profile matrix, RPM, and level), cooling fan, USB charging port, Bluetooth FTMS (connects to fitness apps), C-safe
Programs	manual, hill, fat burn, cardio, HIIT, interval, fit test, 2 HR, constant power, custom
Heart Rate	contact and Bluetooth compatible (chest strap sold separately)
Resistance	40 levels
Drive Train	poly-v belt with self-tensioner
Power	self-generating
Flywheel System	30 lb
Pedals	oversized with fast-latching system
Storage	reading rack, dual seat-mounted trays
Frame	heavy-gauge high-strength steel with durable powder-coat paint
Dimensions	60" L x 29" W x 51" H
Product Weight	164 lb
Max User Weight	450 lb

WARRANTY INFORMATION **Commercial Warranty (Non-dues Paying Facilities)** – Lifetime frame, 5 years parts and electronics, and 2 years labor
Prisons and correctional facilities are excluded from warranty coverage.