



BLUETOOTH 4.0 FTMS
Connects to 3rd Party Apps



OPTIONAL EQUIPMENT
TV Bracket (TV not included)

The CU800 Upright Bike was specifically engineered for the commercial environment, from its heavy-duty steel frame to its durable powder coat paint finish. Features like built-in hand pulse sensors on the multi-position handlebars, as well as the easy-to-read console with a variety built-in programs, satisfy casual and committed users alike. The extra-smooth ride comes from the perfected gearing and the integrated generator/flywheel system.

CU800 UPRIGHT BIKE

- Built-in contact and telemetric heart rate capabilities for a more effective workout
- Generator-powered console means there is no need for outlets or power cords
- Padded ergonomic seat with fore/aft/up/down adjustments provide extra comfort and a customizable fit
- Oversized foot pedals with fast-latching system
- 40 levels of resistance to satisfy the needs of beginners or advanced exercisers
- Adjustable cooling fan and dual storage trays

SPIRIT | 40 YEARS

CU800 UPRIGHT BIKE



18-character message center

Track and program profile window

Tablet-friendly reading rack

Adjustable fan angle

Ten effective programs

Fan on/off

USB charging port

Easy-touch control buttons

CU800 CONSOLE FEATURES

The electronics in the CU800 are designed to provide intuitive operation. The console features a large easy-to-read display with a variety of program options for users of all fitness levels, an integrated fan to keep clients cool, and a USB port to help keep their devices charged. The large multi-position handlebar design includes convenient hand pulse grip sensors for heart rate monitoring on demand.

EQUIPMENT SPECIFICATIONS

Console	white multi-window LED displays (18-character message center, profile matrix, RPM, and level), cooling fan, USB charging port, Bluetooth FTMS (connects to fitness apps), C-safe
Programs	manual, hill, fat burn, cardio, HIIT, interval, fit test, 2 HR, constant power, custom
Heart Rate	contact and Bluetooth compatible (chest strap sold separately)
Resistance	40 levels
Drive Train	poly-v belt with self-tensioner
Power	self-generating
Flywheel System	30 lb
Pedals	oversized with fast-latching system
Storage	reading rack, dual water bottle holders
Frame	heavy-gauge high-strength steel with durable powder-coat paint
Dimensions	49" L x 26" W x 58" H
Product Weight	127 lb
Max User Weight	450 lb

WARRANTY INFORMATION

Commercial Warranty (Non-dues Paying Facilities) – Lifetime frame, 5 years parts and electronics, and 2 years labor

Prisons and correctional facilities are excluded from warranty coverage.