

E-TRi TREADMILL



- Integrated 15" HD personal viewing screen with dedicated intuitively-placed channel and volume controls provides a personalized viewing experience.
- Integrated iPod® connectivity with music, video and USB charging station allows users to display personal content while charging media devices.
- Sturdy hourglass handrail's unique shape improves form and function.
- Centered dual-adjustable personal fans create a more rewarding workout.
- Soft Trac® triple cell cushioning system provides maximum shock absorption.

E-TRi TREADMILL

Model *E-TRi*

user weight capacity	running surface	width	length	height
500 lbs (227 kg)	60" x 20" (152 x 51 cm)	34" (86 cm)	85" (215 cm)	76" (193 cm)

FEATURES AND SPECIFICATIONS

OVERALL WEIGHT: 417 lbs (189 kg)

STEP-UP HEIGHT: 9.5" (24 cm)

FRAME: Custom aluminum uniframe

MOTOR DRIVE: 5 HP AC

ELECTRICAL: 110 volt, dedicated NEMA 5-20 cord; 220 volt, dedicated NEMA 6-15 cord (optional)*

CERTIFICATION: UL/CSA, CE, FCC, or CISPR

SUSPENSION: Soft Trac® triple cell neoprene rubber, Deck System: Reversible 1" (2.5 cm) composite fiberboard, waxing not required

ROLLERS: 3.5" (9 cm) sealed bearings

COLORS: Frame: Star Trac Silver, Shrouds: Slate Gray, Accents: Black

INCLINE RANGE: 0 to 15% in 0.5% increments

SPEED RANGE: 0.5 to 15mph** (0.8 to 24 km/h**) in 0.1 mph (0.1 km/h) increments

HR MONITORING: Polar® Telemetry and Contact Heart Rate System

DISPLAY: Intuitive, tactile response keypad with LED technology

READOUTS: 20-character message window; Dedicated: Speed and incline, time elapsed, calories, distance, course profile, heart rate; Scrolling: Time remaining, vertical distance traveled, laps completed, pace (min/mile or km), calories/hour, 1/4-mile motivational track

PROGRAMS: 12 programs including Dynamic Heart Rate Control®, Constant Heart Control, Fitness Test (Modified Balke Ware), Firefighter Test (Modified Gerkin Protocol), ARMY Protocol, USMC Protocol, USAF Protocol and NAVY Protocol

STANDARD FEATURES: Personal entertainment system, personal cooling fans, wrap-around Aero Bar, dedicated heart rate display, safety lockout control, FitLinxx® certified

ENTERTAINMENT: E Series PVS entertainment system which includes 15" high definition LCD screen, NTSC/ATSC/QAM digital tuner or PAL/SECAM tuner, integrated iPod® connector, USB power port, coaxial cable connector at base

WARRANTY: Motor & MCB—5-year parts and labor; Other parts—2-year parts, 1-year labor; Wear items—1-year parts and labor; Headphone jack, iPod connector, and USB port – 90 day parts, no labor (USA and Canada only)** (Light Commercial warranty for all non dues paying facilities 3 years parts/labor)



©2008 Star Trac. All rights reserved. Star Trac, the Star Trac logo, Soft Trac and Dynamic Heart Rate Control are registered trademarks of Unisen, Inc. Polar is a registered trademark of Polar Electro, Inc. FitLinxx is a registered trademark of FitLinxx, Inc. iPod is a registered trademark of Apple, Inc. *Dedicated 110 volt/20 amp circuit. Mandatory dedicated hot and dedicated neutral wires. Ground wire may be shared by up to four treadmills. Line cord plug: 5-20 NEMA. **Default product settings is 0.5 to 12.5 mph (0.8 to 20 km/h) in 0.1 mph (0.1 km/h) increments. **Parts are covered for a period of two (2) years for the date of purchase and labor is covered for a period of one (1) year from the date of purchase including personal viewing screen and bracket. Wear items, such as drive belts and upholstery are warranted for a period of one (1) year from the date of purchase. Frame welds are warranted for the life of the product. Additional warranties may be available based on facility type and daily usage. (USA and Canada only)